

Nov 2013 9189/5

1 Dilution table

Completing the table -

All values written to 2 d.p, *last digit 0 or 5*

Correct subtraction

Value within the range, *excluding limits*
(28.25 to 28.75)

[1]

[1]

[1]

Table of Titration

Enough titres

All subtractions correct, *not more than one zero starts*

Ticking precise titres and showing calculation of average and completing the summary *correctly: 2 d.p.s, last digit zero or 5*

[1]

[1]

[1]

[1]

[1]

[1]

Working formula:

Ratio: $\frac{\text{Vol. used by Cand}}{\text{titre of Cand}} = \frac{\text{Vol. of Supervisor}}{\text{titre of Supervisor}}$

ACCURACY MARKS

Sp - penalty

Mark	Difference from supervisor			
12	0,001	≤ 0.001	0.20	2
11	0,002	0.001 ⁺ to 0.00299	0.25	3
10	0,004	0.003 to 0.00699	0.30	4
9	0,007	0.007 to 0.01299	0.35	5
8	0,011	0.013 to 0.02099	0.40	6
7	0,016	0.021 to 0.03099	0.45	7
6	0,022	0.031 to 0.04299	0.50	8
5	0,029	0.043 to 0.05699	0.55	9
4	0,037	0.057 to 0.07299	0.60	10
3	0,046	0.073 to 0.09099	0.65	11
2	0,056	0.091 to 0.11099	0.70	12
1	0,075	0.111 to 0.13599	0.80	13
0	>0,075	≥ 0.13600	>0.80	14

IB

(a) $n(\text{AgNO}_3) = \frac{\text{titre} \times 0.005}{1000}$; [1]

(b) (i) $n(\text{X}^-)$ in 25 cm³ of FA1 = $n(\text{AgNO}_3)$ calc. in (a); [1]
 Rxn ratio of $(\text{Ag}^+ : \text{X}^-)$ is 1:1 [1]

$n(\text{X}^-)$ in 250 cm³ of FA1 = ans (b) $\times \frac{250}{25}$ or ans (a) $\times \frac{250}{25}$ [1]

Evaluation of $\frac{\text{titre} \times 0.005 \times 10}{1000}$ to std form / 3 sfg (A) 2dpl

b) ii) Concentration of halide was in the ~~pure~~ water =

~~(b) i)~~ $\frac{n(\text{X}^-) \text{ in } 250 \text{ cm}^3 \text{ FA1}}{\text{Volume of FA1 used}} \times 1000$ or $\frac{\text{ans (b) i)} \times 1000}{\text{Vol of FA1}}$; [1]

(c) More halide ions than just two may be present
 Evaluation to std form or 3 sfg; [1] (A) 2dpl

ASSESSMENT OF PLANNING SKILL

@ least

2. 1. Into a 25 cm³ FA3 add @ titre volume of AgNO₃ to precipitate I⁻ and Cl⁻. [1]
 or specified FA, vol; proportion of vol of titre; (ie $\times \frac{250}{\text{FA}_1}$) ; (2)
2. Fold and open a filter paper into a filter funnel. [1]
 (filter; using filter paper & funnel) [1+1]
3. Filter the ppt and retain residue. [1]
4. Weigh the residue on the filter paper [1]
5. Retain the residue on the filter funnel [1]
6. Wash the residue with ~~Xs~~ dilute ammonia to dissolve AgCl. [1]
7. Reweigh the residue and filter paper [1]
8. (Wash the residue from the filter paper and) weigh the filter paper [1]
9. Calculate the mass of the total initial residue [1]
10. Calculate the mass of residue after washing with dilute ammonia which is AgI. ($M_7 - M_8$) [1]
11. Calculate the mass of AgCl by subtracting the second residue mass from the initial residue. ($M_4 - M_7$) [1]
12. Calculate the ratio of AgCl: AgI ie $M_{11} : M_{10}$ [1] 12

whole # ratio ; (1)
 (divide by smaller)

[14]